

# THIS IS YOUR MAXTON.



We are the centre of excellence for woodwind instruments. We are MAXTON. For ten years we have stood for quality and innovation, always striving for the maximum in terms of sound. Our mouthpieces are manufactured and quality-assured in Austria. We have worked very hard to optimize both, the materials and production methods until we could truly guarantee our unequalled precision. With the help of a revolutionary process, the facing curve is milled onto the mouthpiece. Thus our mouthpieces receive the perfect shape, while you achieve the perfect result.

# TUNE-TOOLS

We offer you the perfect tools to achieve the maximum sound.

## **TONE-RINGS**

Special synthetic rings for a perfect seal between clarinet and mouthpiece. Different sizes allow a very precise fit inside the barrel.

## **DRIVER**

Inconspicuous, but indispensable. The little screwdriver will allow you to loosen and change the rings in one simple move.

## **QUICK GROOVE**


These patented grooves facilitate the changing of the Tone-Rings while preventing damage to the surface. Fast leverage, fast tuning.

## THIS BOX CONTAINS:


- Your MAXTON Mouthpiece
- 1x Driver
- Tone-Rings in different sizes,  
individually selected



## HOW TO QUICK GROOVE.



1. Put the Driver carefully into the Quick Groove.



2. Lift the Driver up to loosen the Tone-Ring.

# QUICK-TIPS

- The mouthpiece cushion protects the mouthpiece. Please do not remove it.
- The Tone-Rings do not need grease or any kind of oil.
- Always use the thickest Tone-Ring on top.
- Insert the mouthpiece centered into the barrel. It needs to fit airtight.
- The reed has to be exactly centered and should end at the top of the mouthpiece. When the reed fits correctly, tighten the ligature, using only a small amount of pressure.
- If the blowing-resistance is too high/low, move the reed very slightly down/up.

# QUICK-TIPS

- Clean and dry your mouthpiece after using it.
- Use a sensitive disinfectant if necessary.
- Wipe off the reed with a cleaning cloth, do not rub or use too much pressure. Pull the cleaning cloth straight and along the bore, always from bottom to top.
- Correct maintenance is very important. Incorrect cleaning may damage your mouthpiece.
- The best depository is your MAXTON box.

**For more information about handling, correct maintenance and about our workshops visit [www.maxton.at](http://www.maxton.at)**



maxton

[maxton.at](https://maxton.at)

Theresianumgasse 11/S1 | 1040 Vienna  
Austria | Europe